Seal re set. Read instructions thoroughly first - use the pictures #2, #3 and #4 to help.

1. Fully extent the wine opener so that the inner barrel is exposed. (Note the needle is sharp use due care) # 2

2. Hold the inner barrel in your left hand and with your right hand twist the safety cap just half a turn to remove it. # 2

3. Hold the Black or Red handle of the wine opener in your right hand and with your left hand unscrew the Silver Top. # 3

4. Carefully push the inner barrel up towards the opening (where the silver top was) Now you can see where the seal should sit on the inner barrel. # 4

5. If the seal is off, place it on top of the inner barrel with the small end of the seal facing down towards the unit. # 4

6. Add a little cooking oil or mineral oil with your fingers or paper towel to the seal and inner barrel. Now to reassemble.

7. Gently push the barrel with seal down inside of the unit until just the seal is exposed.

8. Screw the silver cap back onto the unit - it will push and reset the seal.

9. Pull the inner barrel, which is currently inside the unit; out of the unit.

10. Hold the barrel in your left hand and replace the safety cap (make sure it locks into place).

Once done the process should not need to be repeated for years and years and years but if the seal one day does dry out now you know you can easily lube and reset it.

Silver Top

Inner Barrel

Handle

Safety Cap

2

In step 6 add oil along the inner barrel

3

Seal sitting correctly on the inner barrel

In step 6 add oil here

4